



埋込ボックス使用の場合



取付金具使用の場合



型名	感知器	適合ベース	中継器
FDPJ106-U	FDPJ106-D(ヘッド)	FZB060-2	-
FDPJ206-U	FDPJ206-D(ヘッド)	FZB060-2	-
FDPJ206-U-T	FDPJ206-D-T(ヘッド)	FZB060-2	-
FDPJ206-U-X	FDPJ206-D-X(ヘッド)	FZB060-4	-
FDPJ206-U-S	FDPJ206-D-X(ヘッド)	FZB060-4	FRL014
FDPJ206-U-N	FDPJ206-D-N(ヘッド)	FZB060-2	-
FDPJ206-U-M	FDPJ206-D-M(ヘッド)	FZB060-2	-